

# **WinTool Interface for Esprit TNG**

## **Version 1.6**

### Changes

#### **1.6**

- Replace static gdml.dll reference by runtime load and late binding
- Improved import of driven turning tools

#### **1.5**

- Tool Rotation Z is now with PUT exported
- Ensured compatibility with WinTool Versions older than 2020.3.1
- Compatible with Esprit TNG 5.0

#### **1.4.1**

- Compatible with WinTool 2022.1.0
- Turret and Station ID are now with PUT exported
- ToolShiftY is now imported with Grooving Tools

#### **1.4**

- Compatible with WinTool 2021.2.0
- Cutting Conditions Improved
- Inserts are now correctly designed

#### **1.3**

- Compatible with WinTool 2021.1.3
- Compatible with Esprit TNG R4.9
- New Implementation of the GDML Library

#### **1.2**

- Compatible with WinTool 2021.1
- Compatible with Esprit TNG R4.8
- Improved distinction between Period and Comma on International Esprit's
- New WT-3D Export for Improved 3D Models

#### **1.1**

- Compatible with WinTool 2020.3
- General Tool Improvement

#### **1.0**

- Compatible with WinTool 2020.2
- Compatible with Esprit TNG 20.402